

Spring Miter Clamp Set

General Use Instructions

Version 1.0



Spring Miter Clamps

Spring miter clamps are one of the easiest ways to clamp mitered corners on just about any type of wood project! Great for moldings, trim and frames. Choose the appropriate size spring clamp and use the spreader to open and position the spring clamp, then release.



The spring clamp tips are very sharp. Please wear safety gloves and use extra caution when handling and applying the spring clamps to your project.

Apply Spring Clamp to the Spreader

Attach the proper size spring clamp to the spreader as shown in the image below.

Some spring clamps may require extra pressure to snap on to the spreader by applying pressure to one side of the spring clamp as shown below.



Using the Spreader

The spreader is designed to allow you to easily attach the spring clamp to mitered corners. Simply squeeze the handle, place the clamp at the desired location on the frame, and release the clamp. The spring clamp should be firmly clamping both pieces of stock on your project.



Two Sides

The spreader has two different widths of spring clamp clips. One side is designed for the smaller spring clamps, while the other side is designed for the larger spring clamps.

