



# Baseball inlay Kit Instructions

## Kit components

- 1: 1 x Color Stabilized Barrel with laser cutouts for two Bats & Balls
- 2: 2 x Natural Stabilized Holly Wood Baseballs with detail lines
- 3: 2 x Stabilized Natural Maple Baseball Bats with laser detail Lines



Barrel with laser cutouts



Bat & Ball laser Inlay cutouts

### Step 1:

Remove all components from the plastic bag and place on a clean work surface. Please note that the components are small and you can loose them quite easily. The parts are also fragile and should be handled with care.

### Step 2:

Take the barrel with the laser cutout and slide the brass tube(27/64) into it. **Please do not use any glue** at this stage, this is only to assist you with the assembly process.

### Step 3:

Take the Baseball bat laser inlay and start pressing the pieces into their corresponding openings. The bats can go into any bat opening, their sizes are uniform. The Balls are also the same size but their orientation is important. If you look at [Illustration Nr1](#) you would notice that the smaller/shorter seam facing the bottom of the hole. The ball might not fit if it is placed in any other way. Please use the same orientation as in the pictures in the instructions. Once the all the parts are in place you can use a small piece of wood/penblank to push it completely into position.





Illustration Nr 1



Barrel with laser inlays

## Step 4:

After all the inlay pieces are in place **REMOVE THE BRASS TUBE** from the barrel and then use small amounts of thin CA glue to secure all the pieces into place. Please **do not** soak the whole inlay with thin CA, try to keep the glue to the outer edges of each inlay piece and not in the laser detail lines which will be filled with black dust while turning and finishing the pen.

## Step 5:

Cut the barrel to length but **do not use a Barrel trimmer** it will destroy/break the barrel and all your hard work. Use a disk sander or any other method that will not destroy your blank. Now you can glue the brass tube into place with a glue of your choice and let it dry completely before turning the blank.

It is important to sand the barrel smooth before you are going to use a skew or any other turning tools.

After the barrel is sanded smooth blow the sanding dust out of the laser detail lines and rub some black/dark wood dust into those detail lines. Use thin Ca glue over the whole inlay to secure all pieces into place before turning the barrel to size.

While turning the barrel to size you will notice that some of the laser detail lines will need some more dust filling just repeat filling it with dust and cover with thin CA and continue turning.

Good luck and if you have any questions please do not hesitate to contact me by email or phone. [info@lazerinez.com](mailto:info@lazerinez.com) Tel: 770 891 12301